



## **HP Data Protector 8.00 Device Support Matrix**

Version: 1.9

Date: March 2014

In order for Data Protector to recognize all supported devices ensure that you have the latest Data Protector SCSI Tab file. The file can be downloaded from the web site <http://www.hp.com/support/downloads/>. On the left side, select "Download drivers and software". "Storage Software", "HP Data Protector 8.00 Software" and then any of the HP Data Protector links under "Select your product". Finally, select "Cross operating system (BIOS, Firmware, Diagnostics, etc.)". You can find the link to the SCSI Tab file in the "Software - Utility" section.

There are two matrices that provide the latest Data Protector 8.00 support for storage devices.

The first matrix presents Data Protector 8.00 compatibility with complete Hewlett-Packard Storage Area Network (SAN) environments. Every SAN environment listed in this matrix has been fully tested and is therefore highly recommended for high availability and mission-critical environments. These solutions provide customers 'one-stop shopping' and support for their SAN/FC environments with HP-UX, Windows, HP OpenVMS, Linux, Solaris and IBM AIX operating systems:

[HP Enterprise Business Solutions Compatibility Matrix](#) (on the web page select "EBS Compatibility Matrix")

The second matrix is included in the document and provides a concise list of both media technology and backup devices from all manufactures and vendors that are certified and supported with Data Protector 8.00. All media technologies and devices listed as supported with HP-UX, Windows, HP OpenVMS, Linux, Solaris and IBM AIX operating systems, are supported in both SAN/FC environments and in a direct SCSI-to-SCSI connection

**Note:** The compatibility matrices listed above are not the definitive list of SAN environments supported by Data Protector. These environments are those that have been fully tested and therefore are highly recommended. All media technologies and devices listed as supported with HP-UX, Windows, AIX, Linux, HP OpenVMS and Solaris with *HP Data Protector 8.00 Device Support Matrix* are supported in a SAN environment. The SAN is transparent to Data Protector. All SAN hardware components (HBA, routers, hubs etc.) are supported with Data Protector if the hardware components within the SAN are supported by a vendor or a solution provider.

This matrix displays support for both Storage Area Network (SAN) environments and direct attached storage connections. All media technologies and devices listed as supported with HP-UX, Windows, IBM AIX, Linux, HP OpenVMS and Solaris are supported in both a SAN environment and in a direct attached storage connection. Data Protector supports only library and drive combinations supported by the hardware vendor.

The tables below list the media technology and backup devices that are certified and supported with Data Protector 8.00. If both the media technology and the device/library are listed as supported upon the operating system on which it is to be connected, Data Protector 8.00 support exists.

For example, to employ a HP Surestore 2/20 containing HP LTO Ultrium drives with Data Protector 8.00 upon HP-UX, from checking the two tables below you will see that both the device and media technology are supported. Therefore, this is a supported Data Protector 8.00 configuration.

Although other devices may work with Data Protector 8.00, Hewlett-Packard only supports those listed within this document.

Explanation of symbols used within the matrix:

✓ refers to full Hewlett-Packard support.

● refers to devices that have been qualified as interoperable in HP-UX environments and supported by Data Protector 8.00. Please see the HP web page "[third party mass storage devices](#)". Only certain combinations have been tested and added to the "third party

mass storage devices" matrix, all combinations not listed in the "[third party mass storage devices](#)" matrix are supported through "referenced support" with Data Protector 8.00.

☑ refers to "referenced support". Some combinations have been qualified as interoperable in HP-UX environments and supported by Data Protector 8.00. Please see the HP web page "third party mass storage devices". For all other combinations, "referenced support" incorporates full Hewlett-Packard support for Data Protector 8.00 only. For any device-related issues, please contact the corresponding product vendor first.

In addition, consider the following:

- For all devices listed in tables below, please check the hardware I/O bus configuration with your device vendor to make sure your device also supports the I/O bus architecture.
- Windows Server 2003 StorPort port driver is supported with Windows Server 2003 SP1 class drivers. Windows Server 2003 tape and robotics class drivers need to be enabled. Microsoft recommends to update STORPORT.SYS in Windows Server 2003 SP1 (<http://support.microsoft.com/kb/916048/en-us>) and to update the tape class driver TAPE.SYS (<http://support.microsoft.com/kb/907418/en-us>). Windows Server 2003 with SP1 limits block sizes to 64kB during a tape transfer. This limitation may affect performance of high performance tape drives that use larger block sizes. Larger record sizes are recommended with Ultrium tape devices. In Data Protector larger block sizes are possible up to 1024 kB.
- Data Protector 8.00 supports mixed media libraries. For further information, see the *HP Data Protector Help*.
- Tape pool recycle management and a spare pool configuration is not supported when the tape library is populated with incompatible media from the same media type.
- The IBM AIX Media Agent supports drives only; library robotic must be connected to a system that supports a Data Protector Media Agent with robotics support, that is an HP-UX, Sun Solaris, Linux or a Windows system.
- On HP-UX libraries with more than one SCSI interface, the robotic control is not supported with EISA-SCSI card.

- STK ACSLS libraries are supported in HP-UX, Windows, Solaris SPARC and IBM AIX Media Agents. However, it is possible for all other Data Protector Media Agents to control ACSLS robotics indirectly through the HP-UX, Windows, Solaris or IBM AIX Media Agent.
- ADIC DAS libraries are supported in HP-UX and AIX Media Agents. However, it is possible for all other Data Protector Media Agents to control DAS robotics indirectly through the HP-UX or IBM AIX Media Agent.
- Data Protector magazine support is available only with DDS and DLT tape drives.
- Some devices do not support SCSI auto-configuration and must be configured manually.
- Data Protector enables sharing of multi-drive libraries (libraries with more than one SCSI-II interface) between multiple systems and multiple cells, with robotic control running on an HP-UX, Windows, HP OpenVMS or Sun Solaris system.
- Library drives and robotics can be shared between multiple cells using the Manager-of-Managers server cell and CMMDB (Centralized Media Management Database).
- The library extension license is required for us of libraries with more than 60 slots.
- Magneto-optical WORM (Write Once Read Many) media are not supported by Data Protector. Although all magneto-optical drives do support magneto-optical WORM media, only the magneto-optical re-writable media are supported by Data Protector.
- Data Protector 8.00 supports STK VolSafe WORM media on all supported platforms with the STK9840 tape drive. HP LTO WORM media are supported on HP-UX, Linux, Solaris and HP OpenVMS operating systems. Please note that a "Tape Alert [9]" error will occur on HP-UX 11.31 however, such error can be ignored and will be addressed in the next HP-UX 11.31 "stape" patch.

- It is recommended that no more than 512 drives and 1500 slots be configured for each logical library in Data Protector 8.00.

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	File Library Device	'File'	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Standalone\Jukebox File Device	'File'	✓	✓	✓	✓	✓	✓	✓	✓	✓
	HP Rewritable MO disk	'Optical'	✓	✓	✓	✓					
	HP Rewritable UDO disk	'Optical'	✓	✓	✓	✓					
	DDS-2 SCSI	'DDS'	✓				✓	✓			✓ <sup>9</sup>
	DDS-3 SCSI	'DDS'	✓		✓		✓	✓	✓		
	DDS-4 SCSI	'DDS'	✓	✓	✓	✓	✓	✓	✓		
	DAT72 SCSI	'DDS'	✓	✓	✓	✓	✓	✓	✓	✓	
	DAT160 SCSI	'DDS'	✓	✓	✓	✓			✓	✓	
	DAT24 USB <sup>13</sup>	'DDS'			✓	✓			✓	✓	
	DAT40 USB <sup>13</sup>	'DDS'			✓	✓			✓	✓	

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	DAT72 USB <sup>13</sup>	'DDS'			✓	✓	✓		✓	✓	
	DAT160 USB <sup>13</sup>	'DDS'			✓	✓			✓	✓	
	DAT320 USB <sup>13</sup>	'DDS'			✓	✓			✓	✓	
	DAT320 USB <sup>13</sup> with AES encryption support	'DDS'			✓	✓			✓		
	DAT160 SAS	'DDS'		✓	✓	✓			✓	✓	
	DAT320 SAS	'DDS'		✓	✓	✓			✓	✓	
	DAT320 SAS with AES encryption support	'DDS'			✓	✓			✓		
	HP DLT4000 SCSI	'DLT'	✓		✓		✓	✓	✓		
	HP DLT7000 SCSI	'DLT'	✓		✓		✓	✓			✓
	HP DLT8000 SCSI	'DLT'	✓	✓	✓	✓	✓	✓	✓		✓ <sup>9</sup>
	HP DLT1 SCSI	'DLT'	✓		✓		✓	✓	✓		
	HP DLT VS80 SCSI	'DLT'	✓	✓	✓	✓	✓	✓	✓		
	HP DLT VS160	'DLT'	✓	✓	✓	✓	✓	✓	✓	✓	
	HP DLT V-4 SCSI	'DLT'	☑	☑	✓	✓		✓	✓	✓	

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	HP DLT S4 SCSI	'DLT'	✓	✓	✓	✓			✓	✓	✓
	HP SuperDLT 220 SCSI	'SuperDLT'	✓	✓	✓	✓	✓	✓	✓		✓ <sup>9</sup>
	HP SuperDLT 320 SCSI	'SuperDLT'	✓	✓	✓	✓	✓	✓	✓	✓	✓ <sup>9</sup>
	HP SuperDLT600 SCSI	"SuperDLT"	✓	✓	✓	✓	✓	✓	✓	✓	✓ <sup>9</sup>
	HP LTO Ultrium 215 SCSI	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	
	HP LTO Ultrium 230 SCSI	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	✓ <sup>9</sup>
	HP LTO Ultrium 232 SCSI	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	
	HP LTO Ultrium 448 SCSI	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	
	HP LTO Ultrium 448 SAS	'LTO-Ultrium'		✓	✓	✓			✓	✓	
	HP LTO Ultrium 448c SAS	'LTO-Ultrium'		✓	✓	✓	✓		✓	✓	✓ <sup>9</sup>
	HP LTO Ultrium 460 SCSI	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	✓ <sup>9</sup>
	HP LTO Ultrium 920 SCSI	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	✓ <sup>9</sup>
	HP LTO Ultrium 920c SAS	'LTO-Ultrium'		✓	✓	✓	✓		✓	✓	✓ <sup>9</sup>
	HP LTO Ultrium 920 SAS	'LTO-Ultrium'		✓	✓	✓	✓		✓	✓	✓ <sup>9</sup>





New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	HP LTO Ultrium 3280 FH FC with AES Encryption support	'LTO-Ultrium'	✓	✓	✓	✓			✓ <sup>19</sup>	✓ <sup>19</sup>	
	HP LTO Ultrium 3280 FH SAS	'LTO-Ultrium'		✓	✓	✓	✓		✓	✓	
	HP LTO Ultrium 3280 FH SAS with AES Encryption support	'LTO-Ultrium'		✓	✓	✓			✓ <sup>19</sup>	✓ <sup>19</sup>	
	HP Store Ever LTO-6 Ultrium 6650 FC FH	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	
	HP Store Ever LTO-6 Ultrium 6250 FC HH	'LTO-Ultrium'	✓	✓	✓	✓	✓	✓	✓	✓	
	HP Store Ever LTO-6 Ultrium 6650 SAS FH	'LTO-Ultrium'		✓	✓	✓			✓	✓	
	HP Store Ever LTO-6 Ultrium 6250 SAS HH	'LTO-Ultrium'		✓	✓	✓			✓	✓	
	Benchmark ValuSmart Tape 80	'DLT'		✓	✓	✓	✓	✓			
	Benchmark ValuSmart Tape VS160	'DLT'		✓		✓		✓			
	Dell PowerVault LTO-3 -60	'LTO-Ultrium'			✓						
	IBM 3590B	'T3590'	☑					✓			
	IBM 3590E	'T3590'	☑		✓		✓	✓			
	IBM3590H	'T3590'			✓		✓	✓			

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	IBM3592 TS1120	'T3592'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓		
	IBM3592 TS1130	'T3592'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓		
	IBM3592 TS1140	'T3592'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	IBM Ultrium 3580 LTO 1 (SCSI,FC)	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓		✓	✓			
	IBM Ultrium 3580 Ultrium 2 (SCSI,FC)	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓ <sup>9</sup>		✓ <sup>6</sup>	✓	✓		
	IBM Ultrium 3580 Ultrium 3 (SCSI,FC)	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	
	IBM Ultrium 3580 Half High Ultrium 3 (SCSI,FC)	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	
	IBM Ultrium 3580 LTO3 SAS Half Height	'LTO-Ultrium'		<input checked="" type="checkbox"/>	✓	✓	✓		✓	✓	
	IBM Ultrium 3580 LTO 4 SAS Half Height	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	✓
	IBM Ultrium TS1040 LTO4 FC Full Height	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	✓
	IBM Ultrium 3580 LTO4 SAS) Full Height	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	✓
	IBM Half Height LTO Gen 2 Tape Drive (25R0005)	'LTO-Ultrium'			✓				✓		
	IBM Ultrium TS1040 LTO4 with AES Encryption Support.	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓				✓ <sup>19</sup>	✓
	IBM TS2230 Half High LTO Gen 3 Tape Drive	'LTO-Ultrium'		<input checked="" type="checkbox"/>	✓	✓	✓		✓	✓	
	IBM TS2240 Half Height LTO Gen 4 Tape Drive	'LTO-Ultrium'		<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	
	IBM TS2340 Full Height LTO Gen 4 Tape Drive	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓	✓	✓	✓



New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Certance (Seagate RSS) LTO Ultrium 2	'LTO-Ultrium'				✓	✓			✓	
	Certance (Seagate RSS) LTO Ultrium 3	'LTO-Ultrium'				✓			✓	✓	
	Quantum DLT4000	'DLT'			✓		✓	✓			
	Quantum DLT7000	'DLT'			✓		✓	✓			
	Quantum DLT8000	'DLT'			✓	✓	✓	✓	✓		
	Quantum DLT VS160	'DLT'			✓		✓		✓		
	Quantum DLT V-4	'DLT'	✓	✓	✓	✓		✓	✓	✓	
	Quantum DLT S4	'DLT'	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Quantum DAT72 SATA	'DAT'			✓	✓			✓	✓	
	Quantum DAT160	'SuperDLT'	✓	✓	✓	✓			✓	✓	
	Quantum SuperDLT 220	'SuperDLT'	✓		✓	✓	✓	✓	✓		
	Quantum SuperDLT 320	'SuperDLT'	✓		✓	✓	✓	✓	✓	✓	
	Quantum SuperDLT 600	'SuperDLT'	✓	✓	✓	✓	✓	✓	✓	✓	
	Quantum LTO-3 HH	'LTO-Ultrium'			✓	✓			✓	✓	✓

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Quantum LTO-4 HH	'LTO-Ultrium'							✓		
	Quantum LTO-5 HH	'LTO-Ultrium'			✓	✓			✓	✓	
	Quantum LTO-6 HH	'LTO-Ultrium'		✓	✓	✓		✓	✓	✓	
	STK4220	'T3480'	☑								
	STK9490	'T3480'	☑								
	STK3480/3490e	'T3480'	☑								
	STK9840A	'T9840'	☑		✓		✓	✓	✓		
	STK9840B	'T9840'	●		✓		✓	✓	✓		
	STK9840C	'T9840'	●		✓	✓	✓	✓	✓	✓	
	STK9840D	'T9840'	☑	☑	✓	✓	✓				

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	STK9940A	'T9940'	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>						
	STK9940B	'T9940'	●	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
	STK10000A	'T10000'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
	STK10000B	'T10000'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
	STK10000C	'T10000'	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
	Sun LTO 3 Half Height (HP)	'LTO-Ultrium'	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <sup>9</sup>
	AIT-1	'AIT'		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>					
	AIT-2	'AIT'			<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/> <sup>9</sup>
	AIT-3	'AIT'	<input checked="" type="checkbox"/> <sup>11</sup>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	AIT-4	'AIT'	<input checked="" type="checkbox"/> <sup>11</sup>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	AIT-5	'AIT'	<input checked="" type="checkbox"/> <sup>11</sup>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	Super-AIT	'SAIT'	<input checked="" type="checkbox"/> <sup>11</sup>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
	DTF-1	'DTF'	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>						
	DTF-2	'DTF'	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>						

New	drive technology	configure with Data Protector media type	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Exabyte M2	'ExaByte'			✓						
	Exabyte VXA-3	'ExaByte'			✓						
	Compaq TZ86	'DLT'									✓ <sup>9</sup>
	Compaq TZ87	'DLT'									✓ <sup>9</sup>
	Compaq TZ88	'DLT'					✓	✓			✓ <sup>9</sup>
	Compaq TZ89	'DLT'			✓						✓ <sup>9</sup>
	Compaq TLZ04 4mm DAT	'DDS'									✓ <sup>9</sup>
	Compaq TLZ06 4mm DAT	'DDS'									✓ <sup>9</sup>
	Compaq TLZ09 4mm DAT	'DDS'									✓ <sup>9</sup>
	Spectra Logic RXT150		☑		✓		✓				
	Tandberg 820LTO	'LTO'			✓		✓				
	Tandberg TS1600	'LTO'			✓						
	Tandberg 1640LTO	'LTO'			✓					✓	
	Tandberg HH LTO 2 SCSI	'LTO'	✓	✓	✓	✓	✓		✓	✓	





New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Optical library 80st	✓								
	Optical library 100st	✓								
	Optical library 165st	✓								
	Optical library 300st	✓								
	Optical library 20XT	✓								
	Optical library 20LT	✓								
	Optical library 40T	✓								
	Optical library 120T	✓								
	Optical library 200T	✓								
	Optical 2600fx standalone	✓								
	Optical Jukebox 40fx	✓		✓						
	Optical Jukebox 80fx	✓		✓						
	Optical Jukebox 160fx	✓		✓						
	Optical Jukebox 200fx	✓		✓						

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Optical Jukebox 330fx	✓		✓						
	Optical Jukebox 600fx	✓		✓						
	Optical 5200ex standalone	✓		✓						
	Optical Jukebox 80ex	✓								
	Optical Jukebox 125ex	✓								
	Optical Jukebox 160ex	✓								
	Optical Jukebox 320ex	✓								
	Optical Jukebox 400ex	✓								
	Optical Jukebox 660ex	✓								
	Optical Jukebox 1200ex	✓								
	Optical 9100mx standalone	✓	✓	✓	✓					
	Optical jukebox 220mx	✓		✓						
	Optical jukebox 300mx	✓		✓						
	Optical jukebox 600mx	✓		✓						

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Optical jukebox 700mx	✓		✓						
	Optical jukebox 1200mx	✓		✓						
	Optical jukebox 2200mx	✓		✓						
	Optical 30ux standalone	✓	✓	✓	✓					
	Optical Jukebox 700ux	✓	✓	✓	✓					
	Optical Jukebox 1000ux	✓	✓	✓	✓					
	Optical Jukebox 1100ux	✓	✓	✓	✓					
	Optical Jukebox 1900ux	✓	✓	✓	✓					
	Optical Jukebox 2300ux	✓	✓	✓	✓					
	Optical Jukebox 3800ux	✓	✓	✓	✓					
	Optical Jukebox 7100ux	✓	✓	✓	✓					
	DAT/DDS2 autoloader					✓	✓ <sup>3</sup>			
	DAT/DDS-2 autoloader (48AL)	✓				✓	✓ <sup>3</sup>			
	DAT/DDS-3 autoloader	✓		✓		✓	✓ <sup>3</sup>	✓		

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Surestore Tape 6000i/Eu					✓	✓			
	Surestore 12000e autoloader					✓	✓ <sup>3</sup>			
	Surestore T4i/e						✓ <sup>10</sup>			
	Surestore DAT8i/e/eU	✓				✓	✓			
	Surestore DAT24i/Eu	✓		✓		✓	✓	✓		
	Surestore DAT40e	✓	✓	✓	✓	✓	✓	✓		
	Surestore DAT40i	✓	✓	✓	✓	✓	✓	✓		
	Smart Storage DLT autoloader			✓		✓	✓ <sup>3</sup>			
	Surestore DLT40e/i	✓		✓		✓	✓	✓		
	Surestore DLT70e	✓		✓		✓	✓			✓ <sup>9</sup>
	Surestore DLT80e/i/r	✓	✓	✓	✓	✓	✓	✓		✓ <sup>9</sup>
	Surestore DLT 418 autoloader	✓		✓						
	Surestore 718 DLT autoloader	✓		✓						
	Surestore 818 DLT autoloader	✓		✓		✓	✓ <sup>10</sup>	✓		

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Surestore 1/15, 2/15 DLT library	✓		✓		✓	✓ <sup>10</sup>			
	Surestore 2/28 DLT library	✓		✓		✓	✓ <sup>10</sup>			
	Surestore 2/48, 4/48 DLT library	✓		✓		✓	✓ <sup>10</sup>	✓		
	Surestore 3/30 DLT library			✓			✓ <sup>10</sup>			
	Surestore 6/100 DLT library			✓			✓ <sup>10</sup>			
	Surestore 10/588 DLT library			✓			✓ <sup>10</sup>			
	DDS-2/DAT8 standalone	✓				✓	✓			
	Advanced DLT library	✓				✓	✓ <sup>10</sup>			
	DAT24 SCSI standalone	✓		✓		✓	✓	✓		
	DAT40 SCSI standalone	✓	✓	✓	✓	✓	✓	✓		
	Surestore DAT24x6i/e autoloader	✓		✓		✓	✓ <sup>3</sup>	✓		
	Surestore DAT40x6i/e Autoloader	✓	✓	✓	✓	✓		✓		
	Smart Storage DDS-3 autoloader	✓		✓		✓	✓	✓		
	Smart Storage DDS-4 autoloader	✓		✓		✓		✓		

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Tape Array 5300	✓		✓		✓	✓	✓		
	Tape Array 5500	✓		✓		✓	✓	✓		
	Surestore 1/9 autoloader	✓		✓		✓	✓ <sup>10</sup>	✓		
	Surestore 1/20 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 2/20 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 2/40 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 4/40 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 2/60 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 4/60 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 6/60 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 6/80 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 8/80 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 6/100 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 4/100 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Surestore 10/100 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 6/120 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 6/140 tape library	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		
	Surestore 10/180 Inc. mixed media support	✓		✓		✓	✓ <sup>10</sup>	✓		
	Surestore 20/700 Inc. mixed media support	✓		✓		✓	✓ <sup>10</sup>	✓		
	DLT 40/80 standalone	✓		✓		✓	✓	✓		
	SDLT 220 standalone	✓	✓	✓	✓	✓	✓	✓		✓ <sup>9</sup>
	SDLT 320 standalone	✓	✓	✓	✓	✓	✓	✓	✓	✓ <sup>9</sup>
	SDLT 600 standalone	✓	✓	✓	✓	✓	✓	✓	✓	✓ <sup>9</sup>
	AIT 35/70			✓						
	AIT 50/100			✓			✓	✓		
	AIT 100/200			✓			✓			
	DAT 12/24			✓			✓			
	DAT 20/40			✓			✓			



New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	20/40 GB 8 Cassette Autoloader			✓						
	DAT40x6 Autoloader	✓		✓	✓	✓		✓		
	DAT72x6 Autoloader	✓	✓	✓	✓	✓		✓	✓	
	DAT72x10 Autoloader	✓	✓	✓	✓	✓		✓	✓	✓
	DLT1 1280 SuperLoader			✓						
	1/8 series tape autoloader with DLT VS80 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 series tape autoloader with Ultrium 230 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 series tape autoloader with Ultrium 232 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 series tape autoloader with Ultrium 448 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 series tape autoloader with Ultrium 460 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 series tape autoloader with Ultrium 960 tape drive	✓	✓	✓	✓			✓	✓	
	1/8 series tape autoloader with SDLT320 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 G2 series tape autoloader with Ultrium 232 tape drive	✓	✓	✓	✓			✓	✓	
	1/8 G2 series tape autoloader with Ultrium 448 tape	✓	✓	✓	✓			✓	✓	

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	drive									
	1/8 G2 series tape autoloader with Ultrium 920 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 G2 series tape autoloader with Ultrium 1760 tape drive	✓	✓	✓	✓	✓		✓	✓	
	1/8 G2 series tape autoloader with Ultrium 3000 tape drives	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	StoreEver 1/8 G2 Tape Autoloader with Ultrium 6000 tape drives	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	HP SSL1016 DLT1 tape autoloader	✓		✓						
	HP SSL1016 SDLT320 tape autoloader	✓	✓	✓	✓	✓		✓		
	HP SSL1016 LTO 460 tape autoloader	✓	✓	✓ <sup>7</sup>	✓	✓		✓		
	HP SSL2020TL			✓		✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5026DLX	✓		✓		✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL2024	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP MSL4048	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP MSL5026SL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	HP MSL5026S2	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5026	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5052SL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5052S2	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5052	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5030L1	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5030	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5060L1	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL5060	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP MSL6000	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP MSL6026	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP MSL6030	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP MSL6052	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP MSL6060	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	HP MSL6480		✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	HP MSL8096/8048	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL9198SL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP ESL9198DLX	✓		✓		✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP ESL9198	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL9322S2	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL9322L1	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP ESL9322	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL9595SL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP ESL9595L1	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP ESL9595	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL9595S2	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL9326DX	✓		✓		✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>
	HP ESL9326SL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓		✓ <sup>9</sup>

New	Hewlett-Packard Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	HP ESL9326D	✓		✓		✓	✓ <sup>10</sup>			✓ <sup>9</sup>
	HP ESL9326	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL E-Series 286e	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL E-Series 322e	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL E-Series 630e	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL E-Series 712e	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP ESL G3	✓	✓	✓	✓	✓		✓	✓	
	HP ESL E-Series with Crosslink mechanism	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓ <sup>9</sup>
	HP EML E-Series 71e	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	HP EML E-Series 103e	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	HP EML E-Series 245e	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	HP 6000 Virtual Library System with VLS Accelerated Deduplication <sup>16</sup>	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	✓
	HP VLS 300 EVA Gateway	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	HP VLS 9000 with VLS Accelerated Deduplication <sup>16</sup>	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	









new	HP complementary products Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	QTM4500S DLT autoloader	✓							

new	Quantum (ADIC) Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	FastStor 2			✓		✓		✓	
	FastStor 7			✓					
	FastStor 22			✓					
	SCALAR 24	●	☑	✓					
	SCALAR 100	●	☑	✓			✓ <sup>10</sup>	✓	
	SCALAR 218					✓			
	SCALAR 228					✓			
	SCALAR 448					✓			
	SCALAR 458					✓			

new	Quantum (ADIC) Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	SCALAR 1000 AML/S with SCSI	☑		✓		✓	✓ <sup>10</sup>		
	SCALAR 1000 AML/S with DAS <sup>2</sup>	☑	☑	✓			✓		
	SCALAR 10K with SCSI	●	☑	✓			✓ <sup>10</sup>		
	SCALAR 10K with DAS <sup>2</sup>	☑	☑	✓			✓		
	AML/J <sup>2</sup>	☑	☑				✓		
	AML/E <sup>2</sup>	☑	☑				✓		
	AML/2 <sup>2</sup>	☑	☑				✓		
	Pathlight VX-450 VTL	☑	☑	✓					
	Pathlight VX-650 VTL	☑	☑	✓					

new	Archive Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Archive Python 20/40 DAT			✓				✓	

	Archive Python 12/24 DAT			✓					
<b>new</b>	<b>BDT</b> Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	ThinStor 1/8 Autoloader			✓		✓		✓	
	BDT FlexStor II Family			✓	✓				✓
<b>new</b>	<b>Benchmark</b> Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	ValuSmart Tape 640 Blade			✓		✓		✓	
<b>new</b>	<b>Breece Hill</b> Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Q70 Saguaro					✓			
	Q140 Saguaro					✓			

new	<b>Breece Hill</b> Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Q210 Saguaro					✓			

new	<b>Data Domain<sup>4</sup></b> model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	DDOS 4.7.3	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓
	DDOS 4.8	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓
	DDOS 4.9	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓
	DDOS 5.0	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓
	DDOS 5.1	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓
	DDOS 5.2	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓
	DDOS 5.3	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓
	DDOS 5.4	✓ <sup>15</sup>	✓ <sup>15</sup>	✓	✓	✓	✓ <sup>10</sup>		✓

new	Decru model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	DATAFORT FC-Series	☑	☑	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	DATAFORT S-Series	✓	✓	✓	✓	✓		✓	✓

new	Dell model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Power Vault ML6000 Series	☑	☑	✓	✓	✓	✓ <sup>10</sup>	✓	✓

new	<b>Certance/Seagate</b> <b>Model</b>	<b>HP-UX PA-RISC</b>	<b>HP-UX Itanium</b>	<b>Windows (32-bit)</b>	<b>Windows (64-bit)</b>	<b>Sun Solaris</b>	<b>IBM AIX</b>	<b>Linux (32-bit)</b>	<b>Linux (64-bit)</b>
	Seagate RSS (Certance) Scorpion 40			✓	✓			✓	✓
	Seagate RSS (Certance) Viper 200 LTO (i/e) Standalone			✓	✓	✓	✓	✓	✓
	Seagate RSS (Certance) Viper 2000 Autoloader			✓					
	Certance (Seagate RSS) CD 40 (DDS-4)			✓					
	Certance (Seagate RSS) CD 72 (DAT72)			✓	✓			✓	
	Certance (Seagate RSS) CL 432 (DAT72)			✓	✓			✓	
	Certance (Seagate RSS) CDL 432 (DAT72)			✓	✓			✓	
	Certance (Seagate RSS) CL 200 (LTO Ultrium 1)			✓	✓	✓	✓	✓	✓
	Certance (Seagate RSS) CL 400 (LTO Ultrium 2)			✓	✓			✓	✓
	Certance (Seagate RSS) CL 800 (LTO Ultrium 3)				✓			✓	✓
	Certance (Seagate RSS) CLL 1600 LTO1 Autoloader			✓	✓			✓	✓
	Certance (Seagate RSS) CLL 3200 LTO2 Autoloader			✓	✓			✓	✓

new	EMC Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Disk Library 4000 Series VTL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	Disk Library 300/310 VTL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	Disk Library 700/710/720/740 VTL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	Disk Library 4100/4200/4300 VTL	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓

New	Exabyte Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	220			✓					
	440/480			✓					
	215M			✓					
	430			✓					
	221L					✓			
	224/448			✓					

New	ExaGrid Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	ExaGrid Appliance <sup>22</sup>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

New	FalconStor Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	VirtualTape Library	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>					

New	Fujitsu Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	ETERNUS CS High End <sup>12</sup>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
	ETERNUS CS800	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	LT250	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				



New	Fujitsu Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	LT270	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓				
	LT270S2		<input checked="" type="checkbox"/>	✓	✓				
	ETERNUS LT20			✓	✓				
	ETERNUS LT20 S2			✓	✓				
N	ETERNUS LT270 S2		<input checked="" type="checkbox"/>	✓	✓				
	ETERNUS LT 40			✓	✓				
	ETERNUS LT 40 S2			✓	✓				
	ETERNUS LT60			✓	✓				
	ETERNUS LT60 S2			✓	✓				
	FSC FibreCAT TX 08			✓	✓				
	FibreCAT TX24			✓	✓				
	FibreCAT TX48			✓	✓				
	FibreCAT TX24 S2			✓	✓				
	FibreCAT TX48 S2			✓	✓				

New	GRAU Data Storage Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	INFINISTORE Tape Library/ Model XL	<input checked="" type="checkbox"/>					✓ <sup>10</sup>		

New	Hitachi Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	L1/20 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	
	L2/20 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	
	L2/40 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	
	L4/40 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	
	L2/80 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	
	L4/80 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	
	L6/80 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	
	L8/80 Tape Library	●	●	✓		✓	✓ <sup>10</sup>	✓	

New	Hitachi Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	L20/300 Tape Library	☑	☑	✓	✓	✓	✓ <sup>10</sup>	✓	✓
new	IBM Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	IBM Magstar 3590B11	☑					✓		
	IBM Magstar 3590E11	☑				✓			

new	IBM Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	IBM 3581 Ultrium Tape Autoloader	☑		✓		✓			
	IBM 3582 Ultrium Tape Library	●		✓					
	IBM 3583 Ultrium Tape Library	●		✓			✓ <sup>10</sup>		
	IBM 33614LX LTO3 Tape Library	☑	☑	✓	✓	✓		✓	✓
	TS2900 (3572) Tape Autoloader				✓				
	TS3100 (3573) Tape Library	☑	☑	✓	✓		✓ <sup>10</sup>		✓
	TS3200 (3573) Tape Library	☑	☑	✓	✓		✓ <sup>10</sup>		✓
	TS3310 (3576) Tape Library	☑	☑	✓			✓ <sup>10</sup>		✓
	TS3500 (3584) Tape Library	●	☑	✓		✓	✓ <sup>10</sup>	✓ <sup>5</sup>	✓ <sup>5</sup>
	3600 series			✓			✓ <sup>10</sup>		
	IBM TS7520 VTL	☑		✓		✓			
	IBM TS7530 VTL	☑	☑	✓		✓		✓	
	IBM TS7650 VTL		☑		✓	✓			✓
	IBM TS7650G VTL		☑		✓	✓			✓

new	IBM Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	IBM TS7650AP1 VTL		☑		✓	✓			✓
	IBM TS7610 VTL		☑		✓	✓			✓
	Diligent VTF Open			✓					
	IBM ProtecTIER	☑	☑	✓	✓	✓	✓ <sup>10</sup>	✓	✓

New	KEL Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	EG-4500 Virtual Tape Library		✓	✓	✓				✓

New	MKE Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	MKE DDS-4			✓					

New	NEC Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	iStorage T-Series T40	●	●	✓		✓	✓ <sup>10</sup>	✓	
	iStorage T-Series T80	●	●	✓		✓	✓ <sup>10</sup>	✓	
	iStorage T-Series T180	●	●	✓		✓	✓ <sup>10</sup>	✓	
	iStorage T-Series T700	●	●	✓		✓	✓ <sup>10</sup>	✓	
	DL0101H			✓					
	LL0101H			✓					
	T16A Tape Autoloader	☑	☑	✓		✓			
	T16A2 Tape Autoloader	☑	☑	✓		✓			
	T40A Tape Library	●	●	✓		✓			
	T40A2 Tape Library	☑	☑	✓	✓				
	T60A Tape Library		☑	✓	✓				
	T30A Tape Library		☑	✓	✓				
	LL009F Autoloader			✓	✓	✓			

New	NeoScale Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	CryptoStor Tape 700 Series	✓	✓	✓	✓			✓	✓
New	NetApp Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	NetApp VTL 300	✓	✓	✓	✓	✓			✓
	NetApp VTL 600	✓	✓	✓	✓	✓			✓
	NetApp VTL 700	✓	✓	✓	✓	✓			✓
	NetApp VTL 1200	✓	✓	✓	✓	✓			✓
	NetApp VTL 1400	✓	✓	✓	✓	✓			✓
New	Overland Data Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	PowerLoader Series			✓					

New	Overland Data Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	LoaderXpress Series			✓					
	Neo 100s				✓				
	Neo 200s	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	Neo 200s 2 <sup>nd</sup> Generation	✓	☒	✓	✓		✓ <sup>10</sup>		✓
	Neo 400s	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	Neo 400s 2 <sup>nd</sup> Generation	✓	☒	✓	✓		✓ <sup>10</sup>		✓
	Neo Series 2000	✓		✓	✓		✓ <sup>10</sup>		
	Neo Series 2000e	✓		✓	✓		✓ <sup>10</sup>		
	Neo Series 4100	✓		✓	✓		✓ <sup>10</sup>		
	Neo Series 4100e	✓		✓	✓		✓ <sup>10</sup>		
	Neo Series 4200	✓		✓	✓		✓ <sup>10</sup>		
	Neo Series 4200e	✓		✓	✓		✓ <sup>10</sup>		
	Neo Series 4300	✓		✓	✓		✓ <sup>10</sup>		
	Neo Series 4300e	✓		✓	✓		✓ <sup>10</sup>		



New	Overland Data Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Neo Series 4400	☑		✓	✓		✓ <sup>10</sup>		
	Neo Series 4400e	☑		✓	✓		✓ <sup>10</sup>		
	Neo Series 8000	☑		✓	✓		✓ <sup>10</sup>		
	Neo Series 8000e	☑		✓	✓		✓ <sup>10</sup>		
	Reo Series 1000 VTL	☑		✓			✓ <sup>10</sup>		
	Reo Series 4000 VTL	☑		✓			✓ <sup>10</sup>		
	Reo Series 9000 VTL	☑		✓			✓ <sup>10</sup>		
	ARCvault 12			✓			✓ <sup>10</sup>		
	ARCvault 24			✓			✓ <sup>10</sup>		
	ARCvault 48			✓			✓ <sup>10</sup>		

New	Qualstar Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
-----	-------------------	---------------	---------------	---------------------	---------------------	-------------	---------	----------------	----------------

New	Qualstar Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	TLS-4000 Series			✓	✓	✓	✓ <sup>10</sup>	✓	
	TLS-5000 Series			✓	✓	✓	✓ <sup>10</sup>		
	TLS-6000 Series			✓	✓	✓	✓ <sup>10</sup>	✓	
	TLS-8000 Series			✓	✓	✓	✓ <sup>10</sup>	✓	
	RLS-4000 Series			✓	✓		✓ <sup>10</sup>		
	RLS-5000 Series			✓	✓		✓ <sup>10</sup>		
	RLS-6000 Series			✓	✓		✓ <sup>10</sup>		
	RLS-8000 Series			✓	✓		✓ <sup>10</sup>		
	XLS-8000 Series	☑		✓	✓		✓ <sup>10</sup>		✓

New	Quantum Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	520 series 2/28	☑				✓				

New	Quantum Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	520 series 2/52	<input checked="" type="checkbox"/>				✓				
	520 series 4/52	<input checked="" type="checkbox"/>				✓				
	2640 series 9/88					✓				
	2640 series 6/176					✓				
	2640 series 3/264					✓				
	ATL PowerStor L200					✓	✓ <sup>10</sup>			
	ATL PowerStor L500					✓	✓ <sup>10</sup>			
	ATL P1000			✓		✓	✓ <sup>10</sup>			
	ATL P2000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓		✓	✓ <sup>10</sup>			
	ATL 7100			✓		✓	✓ <sup>10</sup>			
	ATL P3000			✓		✓	✓ <sup>10</sup>			
	ATL P4000	●	●	✓		✓	✓ <sup>10</sup>			
	ATL P7000	●	●	✓		✓	✓ <sup>10</sup>			
	PX720	●	●	✓	✓		✓ <sup>10</sup>			

New	Quantum Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	ATL M1500			✓		✓	✓ <sup>10</sup>			
	ATL M1800			✓		✓	✓ <sup>10</sup>			
	ATL M2500			✓		✓	✓ <sup>10</sup>			
	ATL SuperLoader			✓						
	SuperLoader 3	✓	✓	✓	✓					
	ATL ValueLoader			✓						
	DX30 VTL	✓	✓	✓		✓				
	DX100 VTL	✓	✓	✓		✓				
	DX3000 VTL	✓	✓	✓		✓				
	DX5000 VTL	✓	✓	✓		✓				
	PX502	✓	✓	✓	✓	✓		✓	✓	
	PX506	✓	✓	✓	✓	✓		✓	✓	
	PX510	✓	✓	✓	✓	✓		✓	✓	
	Scalar 50	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	

New	Quantum Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Scalar i40-i80	✓	✓	✓	✓	✓		✓	✓	
	Scalar i500	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	Scalar i2000	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓	
	Scalar i6000	✓	✓		✓	✓			✓	
	DXi3500		✓	✓				✓		
	DXi4701	✓	✓	✓	✓			✓	✓	
	Dxi5500		✓	✓				✓		
	Dxi6500		✓	✓				✓	✓	
	Dxi6700	✓	✓	✓	✓			✓	✓	
	Dxi6701	✓	✓	✓	✓			✓	✓	
	Dxi6702	✓	✓	✓	✓			✓	✓	
	Dxi6802	✓	✓	✓	✓			✓	✓	
	Dxi7500	✓	✓	✓	✓			✓	✓	
	Dxi8500	✓	✓	✓	✓			✓	✓	

New	Quantum Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Dxi8500 2TB	✓	✓	✓	✓			✓	✓	
	Dxi8500 3TB	✓	✓	✓	✓			✓	✓	

New	SEPATON Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	S2100 VTL			✓						

New	SONY Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	SDX-400C AIT-1 series				✓					
	SDX-500C AIT-2 series			✓			✓	✓		



New	SONY Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)	HP OpenVMS
	Sony LIB-D81/A5	<input checked="" type="checkbox"/> <sup>11</sup>								
	Sony LIB-162/A5	<input checked="" type="checkbox"/> <sup>11</sup>								
	Sony Petasite DMS 80/150/8400	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>						
	Sony Petasite CSM-60			<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		
	Sony Petasite CSM-100			<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		
	Sony Petasite CSM-200			<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		

New	Spectra Logic Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Spectra 20k			<input checked="" type="checkbox"/>					
	Spectra 64k			<input checked="" type="checkbox"/>					
	Spectra T50	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>			
	Spectra T50e	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>



New	Spectra Logic Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Spectra T-Finity	<input checked="" type="checkbox"/>		✓		✓		✓	✓
	Spectra T120	<input checked="" type="checkbox"/>		✓		✓		✓	✓
	Spectra T200	<input checked="" type="checkbox"/>		✓		✓		✓	✓
	Spectra T380	<input checked="" type="checkbox"/>		✓		✓		✓	✓
	Spectra T680	<input checked="" type="checkbox"/>		✓		✓		✓	✓
	Spectra T950	<input checked="" type="checkbox"/>		✓		✓		✓	✓
	Spectra T24	<input checked="" type="checkbox"/>		✓		✓			

New	StorageTek Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	STK 280 scratch loader	<input checked="" type="checkbox"/>							
	Lago LS/340 Datawheel					✓			
	Silo Model 4400 with ACSLS	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	✓	✓		

New	StorageTek Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	Silo Model 9310 Powderhorn with ACSLS <sup>1</sup>	☑	☑	✓		✓	✓		
	Silo Model 9360 Wolfcreek	☑				✓	✓		
	STK9710 with SCSI	☑		✓		✓	✓ <sup>10</sup>		
	STK9710 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK 9714 with SCSI	☑		✓		✓	✓ <sup>10</sup>		
	STK 9714 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK 9730 with SCSI	☑		✓		✓	✓ <sup>10</sup>		
	STK 9730 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK 9738 library			✓			✓ <sup>10</sup>		
	STK9740 with SCSI	☑		✓		✓	✓ <sup>10</sup>		
	STK9740 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK L20	●	●	✓		✓	✓ <sup>10</sup>	✓	
	STK L40	●	●	✓		✓	✓ <sup>10</sup>	✓	
	STK L80	●	●	✓		✓	✓ <sup>10</sup>	✓	

New	StorageTek Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	STK L180	●	●	✓	✓	✓	✓ <sup>10</sup>	✓	
	STK L180 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK L700	●	●	✓		✓	✓ <sup>10</sup>	✓	
	STK L700 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK L700E with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK L700E	●	●	✓		✓	✓ <sup>10</sup>	✓	
	STK L1400	☑	☑	✓		✓	✓ <sup>10</sup>	✓	
	STK L1400 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓ <sup>10</sup>		
	STK Silo Model L5500 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓		
	STK SL500	●	●	✓	✓	✓	✓ <sup>10</sup>		
	STK SL500 with ACSLS <sup>1</sup>	●	●	✓	✓	✓	✓ <sup>10</sup>		
	STK SL150	☑	☑	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	STK SL150 with ACSLS <sup>1</sup>	☑	☑	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	SL500 ADI Bridged (SAS)			✓		✓			

New	StorageTek Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	SL500 ADI Bridged (SAS) with ACSLS <sup>1</sup>			✓		✓			
	STK SL8500 with ACSLS <sup>1</sup>	✓	✓	✓	✓	✓	✓		
	SN6000	✓	✓	✓		✓			
	STK C2 Library	✓	✓	✓	✓				
	STK C4 Library	✓	✓	✓					
	SUN StorageTek VTL Plus 2.0	✓	✓	✓	✓	✓			✓
	SUN StorageTek VTL Prime	✓	✓	✓	✓	✓			✓
	SUN StorageTek VTL Plus	✓	✓	✓	✓	✓			
	Sun StorageTek SL24	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	Sun StorageTek SL48	✓	✓	✓	✓	✓	✓ <sup>10</sup>	✓	✓
	Sun StorageTek SL3000 <sup>17</sup>	✓	✓		✓	✓			✓
	Sun StorageTek SL3000 with ACSLS <sup>1</sup>	✓	✓		✓	✓			✓

New	Sun StorEdge Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	L8			✓		✓		✓	
	L9					✓			
	L20					✓			
	L25			✓		✓			
	L100			✓		✓			
	L180					✓			
	L280					✓			
	L700					✓			
	L1000					✓			
	L3500					✓			
	L11000					✓			
	L1400	☑	☑	✓		✓	✓ <sup>10</sup>	✓	
	L5500 with ACSLS <sup>1</sup>			✓		✓	✓		
	L6000 with ACSLS or Libstation <sup>1</sup>			✓		✓	✓		

New	Sun StorEdge Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	C4 Library	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓					

New	Tandberg Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	StorageLoader			✓		✓			
	StorageLibrary T10			✓					
	StorageLibrary T20			✓					
	StorageLibrary T24			✓	✓				✓
	StorageLibrary T40		<input checked="" type="checkbox"/>	✓	✓	✓		✓	✓
	StorageLibrary T40+		<input checked="" type="checkbox"/>	✓	✓	✓		✓	✓
	StorageLibrary T80+		<input checked="" type="checkbox"/>	✓	✓	✓		✓	✓
	StorageLibrary T120+			✓	✓	✓			✓
	StorageLibrary T160+			✓	✓	✓			✓

New	Tandberg Model	HP-UX PA-RISC	HP-UX Itanium	Windows (32-bit)	Windows (64-bit)	Sun Solaris	IBM AIX	Linux (32-bit)	Linux (64-bit)
	StorageLibrary T48			✓					

<sup>1</sup> This device requires the ACSLS software from StorageTek. The following versions of ACSLS have been tested with Data Protector:

- 5.2
- 5.3
- 5.3.2
- 5.4
- 6.0
- 6.01
- 6.1
- 6.1.1
- 7.0
- 7.1
- 7.1.1
- 7.2
- 7.3
- 8.0.x
- 8.1.x
- 8.2.x

HP support covers configuration and usage of ACSLS within Data Protector, but HP provides no support for the ACSLS software. For the MVS-controlled libraries, the following versions have been tested:

- MVS 5.2.2
- Library Station 3.1.0, 4.0, 5.0
- Library Control Facility 3.1.0
- HSC 2.1.0

Note: To utilize ACSLS on Windows, StorageTek LibAttach software is a pre-requisite and must be purchased separately from StorageTek.

<sup>2</sup> This device requires DAS software from ADIC. The following versions of DAS have been tested with Data Protector:

- DAS 1.30
- DAS 1.30C
- DAS 3.01 (single DAS server)
- DAS 3.10

HP support covers configuration and usage of DAS within Data Protector, but HP provides no support for DAS software.

<sup>3</sup> Library or autoloader supported only in stacker mode.

<sup>4</sup> Refer to the Data Domain web link at <http://www.emc.com/products/family/data-domain-family.htm> to get details on the specific models.

<sup>5</sup> To utilize IBM 3584 on Linux, the IBM device drivers are required. These can be obtained from the following web page:

[http://www-1.ibm.com/support/all\\_download\\_drivers.html](http://www-1.ibm.com/support/all_download_drivers.html)

<sup>6</sup> You need to add the line OB2SHORTSEEK=500 in the omnirc file.

<sup>7</sup> Insight Storage Agent should be disabled when using the HP SSL1016 tape autoloader with LTO 460 on Windows XP with the Adaptec U160 SCSI HBA.

<sup>8</sup> TL895 option "Auto Drive Unload" needs to be enabled (which is not the default setting).

<sup>9</sup> Minimum revision of SYS\$MKDRIVER required:

VMS 7.3-1:

image file identification: "X-12"

image file build identification: "X9TD-0060030044"

link date/time: 28-JAN-2004 14:33:50.53

<sup>10</sup> The IBM AIX media agent supports drives only; the library robotic must be connected to a system that supports a Data Protector Media Agent with robotic support which supports the library (that is an HP-UX, Sun Solaris, Linux or Windows system).

<sup>11</sup> To utilize Sony AIT and SAIT on HP-UX, the Sony device driver is required. The driver can be obtained from the following web page:



<http://sony.storagesupport.com/ait/hpux.htm>

12 Emulations supported with the Fujitsu-Siemens CentricStor:

ETERNUS CS Tape Emulation	Drive Configured in Data Protector	CentricStor Robot Control Emulation	Robotic Configured in Data Protector	HP-UX PA	HP-UX IA	Windows	Solaris	Linux	AIX
Generic SCSI-2	3480	SCSI	SCSI Library	✓		✓	✓	✓	
Generic SCSI-2	3480	DAS	DAS Library	✓		✓			
Generic SCSI-2	3480	ACSL	ACSL Library	✓		✓	✓		
Mammoth 2	Exabyte	SCSI	SCSI Library		✓	✓	✓		
Mammoth 2	Exabyte	DAS	DAS Library		✓	✓			
STK9840B	9840	ACSL	ACSL Library	✓	✓	✓			
IBM 3590 E1A	3590	DAS	DAS Library		✓				✓
IBM 3590 E1A	3590	ACSL	ACSL Library						✓
IBM 3590 E1A	3590	SCSI	SCSI Library	✓		✓			✓
IBM Ultrium LTO2	LTO Ultrium	ACSL	ACSL Library		✓				
IBM Ultrium LTO2	LTO Ultrium	DAS	DAS Library		✓				
IBM Ultrium LTO2	LTO Ultrium	SCSI	SCSI Library		✓				

13 To utilize HP USB devices on Windows, the HP Mass Storage Driver (HPUSBMSC.SYS) driver is required.

14 When using iSCSI initiator software, only SUSE Linux Enterprise Server (SLES) 10 SP2 and SLES11 are supported.

15 The IBM LTO device driver is required. This can be obtained from the following URL: [http://www-1.ibm.com/support/all\\_download\\_drivers.html](http://www-1.ibm.com/support/all_download_drivers.html). Please Note: The native operating system driver should be used for the library robotic. Please reference Data Domain Compatibility Matrix for further detail: [https://support.datadomain.com/compat\\_matrix.php](https://support.datadomain.com/compat_matrix.php)

16 Minimum device firmware required for VLS Accelerated Deduplication: 3.4.0 for VLS 6200/6600/9000/12000 and 6.0.0.2 for VLS 9200/12200.

17 SL3000 AEM import/export slots is currently limited to 99 import/exports per job. This limitation is being reviewed and will be fixed within a future Data Protector patch.

18 Supported only with SUSE Linux Enterprise Server (SLES) 10 SP2, SLES 11 and RHEL 5.4.

19 Details of supported Linux distributions for drive based encryption are available in the *HP Data Protector 8.00 Platform and Integration Support Matrix*.

21 To utilize IBM LTO with AES Encryption support on HP-UX, the minimal IBM firmware version required is B711. This firmware can be obtained from the following web page : <http://www-933.ibm.com/support/fixcentral>

22 File devices created on the ExaGrid NAS appliances are supported.

Note: For information on the Data Protector omnirc file, see the *HP Data Protector Help*.